

TO: West Mason C of C

2-26-2020

Instructions for changing the WiFi password on the Soundcraft Ui mixer:

Locate the setting gear and open

Locate Network and open

Locate HotSpot and open

Locate Config and open

Follow the instructions to change the security settings

The current password is scuiwlan



1233 Castle Dr. Ste A5
Mason, Oh. 45040

Phone: 513-703-0147

customerservice@soundconceptsllc.com
Web site: www.soundconceptsllc.com