

Operation Guide Sanctuary Audio System

The system is operated through the use of an iPad or other tablet or personal computer. There is a website/control system built into the mixer which allows a device with network access to control the system. Access is through connection to the Access Point installed in the corridor directly off of the Sanctuary. Following are connection and operation procedures for control of the system

1. The system is powered on using a sequencing device which is activated by the small toggle switch on the outside of the equipment rack located in the Audio Room. To operate the system set the switch to the “ON” position.
2. The system control is implemented through the use of a network system and as such it takes about 2 minutes for the system to fully enter into operation mode. The microphones may work sooner than that but full control of levels will require the full network setup to complete. There is no user interface in this part of the operation.
3. Make sure the iPad (or other interface device) is fully charged and powered on.
4. If necessary, make sure that the iPad's WiFi is set to the control WiFi Access Point:
 SSID: CCS-Audio_2.4 or CCS-Audio_5
 Password: MbEddy!!
5. Once the iPad is connected to the network, select the icon marked “UI” on the home screen of the iPad. The mixer control screen with the volume control faders should appear and provide control of the system.

Alternative connection method:

Access can also be gained to the control screen by opening the Safari browser and entering the IP address 192.168.0.3 into the address bar and hitting select. This will also open the control screen.

If connection fails make sure that the iPad's WiFi did not automatically change to the church's internet WiFi.



1233 Castle Dr. Ste A5
Mason, Oh. 45040

Phone: 513-703-0147

customerservice@soundconceptsllc.com
Web site: www.soundconceptsllc.com



**1233 Castle Dr. Ste A5
Mason, Oh. 45040**

Phone: 513-703-0147

**customerservice@soundconceptsllc.com
Web site: www.soundconceptsllc.com**